


ALTER

Alter ELETTRONICA s.r.l.
15033 Casale Monferrato (AL) – ITALY



13/013

Converter module Serial Encoder / Encoder TTL

Manual Instructions: 91/122 - Version 5.3 - Date: 28/04/2026

Compatible with Firmware V5.x

Chapter 1 - Index

General Index

Chapter 1 - Index.....	2
Chapter 2 - Safety information.....	3
Chapter 3 - Technical characteristics.....	4
3.1 - Generality.....	4
3.2 - Identification plate.....	5
3.3 - Technical data.....	6
3.4 - Functional scheme.....	6
Chapter 4 - Installation.....	7
4.1 - Preliminary operations.....	7
4.2 - Connection power supply services (X1).....	7
4.3 - Signal connections.....	7
4.3.1 - Analog input connector (X2).....	7
4.3.2 - Connector analog outputs (X3).....	7
4.3.3 - Can Bus connector (X4).....	8
4.3.4 - USB connector (X5).....	8
4.3.5 - Serial encoder input connector (X6).....	8
4.3.6 - Emulated encoder output connector (X7).....	10
4.3.7 - Signal output connector Frequency/direction (X8).....	10
4.3.8 - Digital input connector (X9).....	11
4.3.9 - Digital output connector (X10).....	11
4.4 - Restarting after an alarm.....	12
Chapter 5 - Commissioning.....	13
5.1 - Predispositions.....	13
5.2 - Introduction to PC software.....	13
5.3 - Activation of the communication port.....	13
5.4 - How to Change Values.....	14
5.5 - Rapid commissioning.....	14
5.5.1 - Connection to an ALTER drive model PWM3D.....	14
5.5.2 - Connection to equipment that does not use Hall sectors.....	15
5.5.3 - Connection to a generic drive.....	15
5.6 - Setting the module parameters.....	16
5.7 - Setting up digital inputs.....	16
5.8 - Setting digital outputs.....	17
5.8.1 - Signal sources for digital outputs.....	17
5.9 - Setting analog outputs.....	17
5.10 - Verification of encoder operation.....	18
5.11 - Frequency/direction output verification.....	18
5.12 - Encoder phasing.....	18
5.13 - Save/Restore Parameters.....	19
5.13.1 - Transfer parameters from module to PC.....	20
5.13.2 - Transfer parameters from PC to module.....	20
5.14 - Module alarms.....	21
5.14.1 - Reset alarms.....	22
5.15 - Diagnostics.....	22
Chapter 6 - Annexes.....	23
6.1 - Led Summary Table.....	23
Chapter 7 - Mechanical characteristics.....	24

Chapter 2 - Safety information

- Read this manual carefully before using the module 13/013.
- Keep the manual carefully and in a place of easy access in order to consult it later in case of need.
- Make sure this manual is delivered to the end user.

The safety symbols used in this manual are described below:

	DANGER: This symbol indicates the possibility of even serious injuries to people, due to electrical or mechanical shocks.
	ATTENTION: This symbol indicates the possibility of damage to things or to the module itself.
	WARNINGS: Additional information useful for proper use of the module.



- ✓ Make sure that the power supply voltage of the module matches the plate data.
- ✓ Never feed the module without the lid and never remove the lid while the power supply is present.
- ✓ Do not perform manipulations on the module with wet hands. There is a danger of electrical shocks.
- ✓ Before starting wiring make sure there is no power supply.
- ✓ All power sources must be disconnected before any maintenance is carried out.
- ✓ Maintenance, inspection and replacement shall be carried out by a designated person.



- ✓ Always fix the module before wiring.
- ✓ The installation must be carried out by qualified technical personnel.
- ✓ To comply with the regulations on electrical safety, make the mass connections according to the standards of the country where the module is installed.
- ✓ Install a protective circuit (fuse or magnetic switch) on the module power supply.
- ✓ Never change the module.
- ✓ Clean the module with a vacuum cleaner. Do not use organic solvents. There is a danger of damaging the module.
- ✓ It is essential for your safety that any revision of the module is carried out by our company.
- ✓ In the case of disposal, the module must be considered an industrial waste, therefore comply with the rules imposed by the laws in force in the country in which it is installed.

The module 13/013 complies with the following industrial standards:

Standard/Marking	Description
CEI EN 60204-1	Low voltage safety directive, 73/23/EEC.
CEI EN 61800-3	Product standard related to EMC Directive 89/336/EEC.
CEI EN 60529	Degree of protection IP20.
EC	CE marking.

Chapter 3 - Technical characteristics

3.1 Generality

The module's function 13/013 is to convert the signal of a serial encoder into an incremental TTL Line Driver encoder with Hall sensors.

Serial encoder compatibility list:

	Compatible	Not compatible
FANUC	• αi64 (Type: A860-0365). • αiAR128 (Type: A860-2010-T341). • αiA1000 (Type: A860-2000). • α64iA (Type: A860-2014-T301). • αA64 (Type: A860-0360-V501 e A860-0360-T001). • αiA16000 (Type: A860-2001-T301). • βiA128 (Type: A860-2020-T301). • αA1000 (Type: A860-0370-V502).	• βiA1000 (Type: A860-2070-T321). • αiA32000 (Type: A860-2051-T321). • αiA4000 (Type: A860-2050-T321).
mitsubishi	• OSA17. • OSA18-130. • HA300NC-S. • HC-SF. • HF303BS-A48.	

The module signals the alarms in the encoder and self-configures with the parameters of it.

In addition, the module provides a digital +24V output to signal faults and block motor operation or other accessories.

All commands are opto-isolated and run at 24Vcc in positive logic and can be generated by: buttons, relay contacts, PLC outputs, etc. and come from one or more points.


The digital outputs are opto-isolated, run at 24Vcc in positive logic and are electronically protected against overload and short circuit. The status of commands and outputs is displayed with Led.

All settings are made with a PC connected to the module's USB port using the software provided by ALTER, and are stored inside the module.

The electronic circuits and I/O connectors are on a printed circuit board placed inside a metal case to have the best shielding against disturbances.

The alarms are stored in the module, can be displayed via the PC and reset via a special digital input.

3.2 Identification plate



Explanation of the various fields of the plate:

1. Manufacturer's name, address, contacts.
2. Supply voltage auxiliary services.
3. Version of Firmware loaded into the module.
4. Serial number of the module.
5. Type of module.
6. Model of the module.

All other spaces not indicated, are not used in this product.


3.3 Technical data

- Execution for fixing on panel. Degree of protection IP20.
- Ambient operating temperature: from 0 °C to +40 °C.
- Storage temperature: from -10 °C to +70 °C
- Relative humidity max.: 95 % without condensation.
- Maximum altitude: 1000 m. a.s.l.
- Single-phase service supply: 85÷264Vca (47÷63Hz), 120÷370Vcc – 500mA max (protection with delayed fuses 250V – 1A).
- Over-voltage protection on:
 - Signal inputs and outputs.
 - Service supplies.
- Service connections and signals on removable connectors
- Opto-isolated logical inputs (command from 15 to 30Vcc – 10mA max).
- Opto-isolated logic outputs (24Vc. – 100mA max) protected against overload and short circuit.
- Analog outputs in voltage, with resolution 14 bit + sign ($\pm 10V$ max. – output resistance 100 Ω).
- Power outputs for references:
 - +24V $\pm 1\%$ – 100mA max.
 - +10V $\pm 5\%$ – 5mA max.
 - -10V $\pm 5\%$ – 5mA max.
- LED display of digital I/O logical states, present alarms, working module.
- Diagnostics and programming with software on PC (Windows), with the ability to copy configurations from PC to module and vice versa.
- Signaling anomalies and alarms on a digital output.

3.4 Functional scheme

In the following figure you can see a functional diagram of the module that represents all the inputs, the outputs available, with the relative commands and signals, as in the factory standard configuration.

Some inputs and outputs can be modified by the customer according to their needs.



Drawing 1: Functional diagram of the module

Chapter 4 - Installation

4.1 Preliminary operations

- Check that the module has suffered no damage in the transport.
- Mount the module vertically away from heat sources.
- Use unpainted sheet fixing panels connected to the ground.
- Connect to a good ground one of the ground terminals placed on the sides of the module.
- Follow the link patterns shown in the manual.
- Use shielded cables for signal connections.
- Connect to the ground on the carpentry or on the terminals arranged on the two ends of the shields.
- Do not use terminal blocks but only shielded connectors for signal shielded cable junctions.
- Mounting noise suppressors (off for c.a./diodes per d.c.) parallel to the coils of all contactors, relays, solenoid valves, single-phase motors, three-phase motors, etc.

4.2 Connection power supply services (X1)



The service supply is connected to the removable connector identified with the **ACL** and **ACN** inscriptions at the top of the module; this supply voltage can be supplied by an alternating current or direct current network without any particular setting.

In the case of AC power supply, the voltage shall be between 85 and 264Vac (frequency from 47 to 63 Hz); instead, in the case of continuous power supply the voltage must be between 120 and 370Vdc.

In both cases it is mandatory to protect the module with a pair of fuses adapted to the voltage used, with a current size of 1A delayed.

4.3 Signal connections

With reference to drawing 16 on page 24, starting from the upper side of the module we find the signal connectors that are described in the following paragraphs.

4.3.1 Analog input connector (X2)

NAME	DESCRIPTION	
+10V	Output +10Vcc $\pm 5\%$ – 5mA max.	
-10V	Output -10Vcc $\pm 5\%$ – 5mA max.	
A0V	0V analog. The analog 0V is connected to the module case.	
AI1+	Hot pole of the analog input 1.	<u>Not used.</u>
I1-	Cold pole of the analog input 1.	
AI2+	Hot pole of the analog input 2.	<u>Not used.</u>
I2-	Cold pole of the analog input 2.	
AI3+	Hot pole of the analog input 3.	<u>Not used.</u>
I3-	Cold pole of the analog input 3.	
A0V	0V analog. The analog 0V is connected to the module case.	

Features common to all analog inputs:

- Maximum voltage: $\pm 10V$ between pole + and pole – or with respect to A0V.
- Input resistance: 110K Ω .
- Resolution: 11 bit + sign or 15 bit + sign.

Always use good quality shielded cables and connect the two ends of the shield to the ground. On the module case, near the connectors, anchorages are available for the shields.

4.3.2 Connector analog outputs (X3)

NAME	DESCRIPTION
AO1	Analog output 1. <u>Angular position encoder.</u>
A0V	0V analog. The analog 0V is connected to the module case.

NAME	DESCRIPTION
AO2	Analog output 2. <u>Not in use.</u>
A0V	0V analog. The analog 0V is connected to the module case.
AO3	Analog output 3. <u>Not in use.</u>
A0V	0V analog. The analog 0V is connected to the module case.

Features common to all analog outputs:

- Maximum voltage: $\pm 10V$ (or $0 \div 10V$) between the output pole and A0V.
- Output resistance: IT'S 100 Ω .
- Resolution: 14 bits plus sign.

Always use good quality shielded cables and connect the two ends of the shield to the ground. On the module case, near the connectors, anchorages are available for the shields.

NOTE: Due to the output resistance of 100 Ω , it should be considered that it may be necessary to adjust the gain of the analog output to reach the value of 10V indicated in the characteristics. For example: if the analog output is connected to an analog input of a drive having an input resistance of 10K Ω , it must be considered that from vacuum to load the signal will fall by about 1 %, so instead of 10V we will have 9.9V.

4.3.3 Can Bus connector (X4)

NAME	DESCRIPTION
TRM	Insertion of the bus termination resistance.
H	Can bus wire H.
L	Can bus wire L.
A0V	0V analog. The analog 0V is connected to the module case.

NOTE: in this module the "Can Bus" connector is not used.

4.3.4 USB connector (X5)

This connector is used to connect a USB cable type B to the PC for programming, diagnostics, saving parameters. For more information see the section 5.2 on page 13.


4.3.5 Serial encoder input connector (X6)

This connector is used to connect the encoder to the module: It is mandatory to use a shielded cable with the conductors twisted in pairs to have a cleaner and more immune signal to possible disturbances and the shield must be grounded from both ends.

4.3.5.1 Fanuc Pulsecoder serial encoder

To the module 13/013 you can connect a Fanuc serial encoder of your choice between the models indicated in paragraph "Generality" on page 4. To use other models, please contact our technical office.

The encoder shall be connected to the X6 connector according to the following table:


	ENCODER SIGNAL INPUT (X6)		CONNECTION	ENCODER FANUC
	SIGNAL	N. PIN		SIGNAL
	+5V (positive feeding encoder)	1		+5V
	0V (Power supply 0V encoder)	2		0V
	Pair shield REQ	8		
	Req+ serial interface	9		REQ
	REQ- serial interface	10		*REQ
	SD pair shield	16		
	SD+ serial interface	17		SD
	SD- serial interface	18		*SD
	0V (cable shield) – Connector box		-SHIELD-	SHD


View of the connector type "D" 25 poles female on the welding side.

There are various types of connectors on the Encoder side, below some known models:

TYPE 1		
SIGNAL	N. PIN	
+5V	K	
0V	T	
REQ	F	
*REQ	G	
SD	A	
*SD	D	

TYPE 2		
SIGNAL	N. PIN	
+5V	8	
0V	7	
REQ	6	
*REQ	5	
SD	2	
*SD	1	
SHD	3	


TYPE 3		
SIGNAL	N. PIN	
+5V	13+14	
0V	3+4	
REQ	7	
*REQ	9	
SD	8	
*SD	10	

TYPE 4		
SIGNAL	N. PIN	
+5V	8+15	
0V	2+10	
REQ	5	
*REQ	6	
SD	12	
*SD	13	


4.3.5.2 Mitsubishi serial encoder


To the module 13/013 you can connect a Mitsubishi serial encoder to choose from among the models indicated in paragraph "Generality" on page 4. To use other models, please contact our technical office.

The encoder shall be connected to the X6 connector according to the following table:


	ENCODER SIGNAL INPUT (X6)		CONNECTION	ENCODER MITSUBISHI	
	SIGNAL	PIN		SIGNAL	
	+5V (Power +)	1		+5V	
	0V (Power supply 0V)	2		0V	
	SD (RX serial data)	3		SD	
	SD (RX serial data)	4		SD	
	SD pair shield	5			
	RQ (TX serial data)	6		RQ	
	RQ (RX serial data)	7		RQ	
	RQ pair shield	8			
	0V (cable shield) – Connector box		-SHIELD-	SHD	

Vista del connettore volante tipo "D" 25 poli femmina dal lato saldature.

CONNECTOR MS-19			CONNECTOR CM10-R10P		
SIGNAL	PIN		SIGNAL	PIN	
+5V	S		+5V	8	
0V	R		0V	5	
SD	H		SD	6	
SD	J		SD	7	
SHD			SHD	10	
RQ	K		RQ	1	
RQ	L		RQ	2	

CONNECTOR MS-17		
SEGNALE	N° PIN	
+5V	S	
0V	R	
SD	A	
SD	B	
SHD	N	
RQ	C	
RQ	D	

4.3.6 Emulated encoder output connector (X7)

	EMULATED ENCODER OUTPUT (X7)		CONNECTION	CNC or DRIVE	
	SIGNAL	N. PIN		N. PIN	SIGNAL
	Channel "A" line-driver 5V	1			
	Channel "A" line-driver 5V	2			
	Channel "B" line-driver 5V	3			
	Channel "B" line-driver 5V	4			
	Channel "Z" line-driver 5V	5			
	Channel "Z" line-driver 5V	6			
	0V	9	-		
	HALL sector "SE1" line-driver 5V	10			
	HALL sector "SE1" line-driver 5V	11			
	HALL sector "SE2" line-driver 5V	12			
	HALL sector "SE2" line-driver 5V	13			
	HALL sector "SE3" line-driver 5V	14			
	HALL sector "SE3" line-driver 5V	15			
	0V (cable shield) – Connector box				

View connector from the welding side (Connector type "D" 15 pole female).

This connector is used to send the signal of the emulated encoder to the CNC (or other users): it is identical to the signal provided by a classic incremental TTL Line Driver square wave encoder with 4096 ppr (Pulse/turn) per channel.

If necessary, the setting of generated PPRs can be changed: See explanations for the configuration in the paragraph 5.6 on page 16.

Also on this connector it is advisable to use shielded cable with twisted conductors in pairs.

4.3.7 Signal output connector Frequency/direction (X8)

NAME	DESCRIPTION
F+	Frequency signal (Line Driver 5V – Direct Pole)
F-	Frequency signal (Line Driver 5V – Reverse Pole)
D+	Direction signal (Line Driver 5V – Direct Pole)
D-	Direction signal (Line Driver 5V – Reverse Pole)

There are two signals on this connector: frequency and direction. Generally these signals are used in step-by-step motor drives and can also be called “Step/Direction”. For each turn of the encoder, a number of pulses (setable) on the Frequency signal are generated. The two signals have this meaning:

- **Frequency:** on these terminals there is a variable frequency signal with the speed of the resolver. You can set the number of pulses/turns that will be generated from 3 to 65000, referring to a turn of the encoder. Maximum frequency 4000 KHz.
- **Direction:** on these terminals there is a signal indicating the direction of rotation of the encoder (therefore the speed sign): D+ = 0V if the direction is positive, D+ = 5V if the direction is negative. Obviously the logical state of D- is the inverse of D+.

If the counting direction is opposite to the desired direction, you can reverse it by exchanging the wires connected to D+ and D-.



4.3.8 Digital input connector (X9)

NAME	DESCRIPTION
DI1	Digital input 1: <u>reset alarms</u>
DI2	Digital input 2: <u>command INCREASES</u> electrical angle offset
DI3	Digital input 3: <u>command DECREASES</u> electrical angle offset
DI4	Digital input 4: <u>unused</u>
DI5	Digital input 5: <u>unused</u>
DI6	Digital input 6: <u>unused</u>
DI7	Digital input 7: <u>unused</u>
DI8	Digital input 8: <u>unused</u>
DI9	Digital input 9: <u>unused</u>
D0V	0V digital inputs.
A0V	0V analog. The analog 0V is connected to the module case.
+24V	Power supply +24V – 100mA max.

Power supply voltage from 18Vcc to 30Vcc (nominal 24Vcc). The 24Vcc power supply can be supplied by the module itself (if the total current absorbed by the loads connected to the outputs does not exceed 100mA): Connect D24 with terminal +24V (see paragraph 4.3.9) and D0V with A0V terminal. If the internal power supply cannot be used, an external power supply must be used.

The status of each digital input is displayed by the corresponding LED which indicates that the command is valid (see paragraph 6.1 on page 23).

Examples of connections to digital inputs:



4.3.9 Digital output connector (X10)

NAME	DESCRIPTION
+24V	Power supply +24V – 100mA max.

NAME	DESCRIPTION
D24	Common to connect to +24Vcc for digital outputs.
DO1	Digital output 1: <u>OK module</u> .
DO2	Digital output 2: <u>"Communication Initialized" signal</u> .
DO3	Digital output 3: <u>"Position Initialized" signal</u> .
DO4	Digital output 4: <u>"Timeout Serial Communication Error" Signal</u> .
DO5	Digital output 5: <u>"serial data error" signal</u> .
DO6	Digital output 6: <u>"Encoder internal fault" signal</u> .

Power supply voltage from 18Vcc to 30Vcc (nominal 24Vc.c.). The 24Vcc power supply can be supplied by the module itself (if the total current absorbed by the loads connected to the outputs does not exceed 100mA): Connect D24 with terminal +24V and D0V with A0V terminal (see paragraph 4.3.8). If the internal power supply cannot be used, an external power supply must be used.

States of outputs:

Off = Floating

On = Connected to +24V power supply (D24) (marked by the power on of the corresponding led)



Without service power all outputs are OFF.

Maximum current for each output 100 mA, voltage drop inside the maximum current 2V. In case of overload or short circuit on one or more outputs all the outputs are forced into the OFF state permanently and the module signals the anomaly.

The state of each digital output is displayed by the corresponding LED indicating that the output is controlled (see paragraph 6.1 on page23).

NOTE: The GREEN LEDs of this module that signal the status of the corresponding digital output from DO3 to DO5, are flashing when the signal is active (so the digital output is 24V), because they are alarms or warnings of malfunctions.

Examples of connections to digital outputs:



4.4 Restarting after an alarm



When the module enters alarm status (DO1 output = OFF and flashing of the red FLT LED) the truthfulness of the output signals (Frequency/Direction, emulated encoder) is not guaranteed, so the user must take steps to avoid faults or dangers to things or people.

After detecting the cause of the alarm, the module may be reset by one of the modes indicated 5.14.1 in paragraph on page 22.

Chapter 5 - Commissioning

To configure the module you need to be provided with:

1. A PC with Windows operating system.
2. A free USB port on your PC (you can also use a Hub Usb).
3. A USB connection cable type B (the one used for USB printers).
4. The software to be uploaded to the PC to interface to the module (supplied by Alter on request).
5. The driver for USB connection (if an Internet connection is available, this is not necessary as the module is Plug & Play and the driver is automatically downloaded).

In the absence of one of the above points it will not be possible to configure or do a diagnostic of the module.

NOTE: *this manual does not deal with the topic of installing the software, drivers or other problems related to compatibility with the PC supplied to the customer. In case of need, you can contact the ALTER technical office. Putting into service presupposes that the customer's PC is configured and ready to use.*

5.1 Predispositions

Before setting the parameters in the module it is mandatory to follow these points:

- Connect the cable between Encoder and X6 connector as indicated in paragraph 4.3.5 on page 8.
- Connect the cable between the drive (or other user of the emulated encoder) to the X7 connector as specified 4.3.6 in paragraph on page 10.
- Supply the auxiliary power supply to the appropriate terminals (see paragraph 4.2 on page 7).
- All the LEDs will turn on for 3 seconds (Led Test), then most of them will turn off.
- Check that the green LED "ON" is flashing. For the moment the other LEDs don't matter.
- Connect a head of the USB cable to the module X5 connector and the other end to a free USB port in the PC.
- If necessary, wait for the PC to install the driver for the module.
- Launch the programming software on your PC.

5.2 Introduction to PC software

After starting the application on your PC, go to the top menu and click "File → Open Project", select the project "13-013_V05xx_EN.pmp". At this point you have 4 zones where you can see different data:

1. At the top we find the "**Toolbar**" with various buttons to perform some functions.
2. On the left side we find the "**Project Tree**" where you can select the various groups of parameters that have been assembled for simplicity, the various oscilloscopes to analyse low rate signals or recorders to analyse fast signals.
3. At the bottom we find the "**Variable Watch**" where the variables will be displayed with their real-time updated value, the parameters to be modified and any commands (reset alarms, save parameters, etc.).
4. In the central part we find an area that can change functioning according to the context. In this part we can find:
 1. "**Algorithm block description**" showing drawings or instructions to facilitate calibration or to clarify the meaning of the variables listed in the "Variable Watch" part.
 2. "**Oscilloscope**" in which you see some variables (maximum 8) displayed in graphic form relative to a time base or compared to another variable (Graph X-Y). The update of these variables is related to the bit-rate of communication between PC and module, so changes in fast signals cannot be represented.
 3. "**Recorder**" in which you see some variables (maximum 8) displayed in graphic form relative to a time base or compared to another variable (Graph X-Y). The update of these variables is related to the speed of the fastest cycle (which can be seen in the menu "Diagnostics" parameter "Fast cycle: period"), so it is able to represent variables that change in the order of microseconds.

Without going into the details of all the functions of the various menus and buttons, the following paragraphs will explain how to configure the module using the software on the PC to allow a quick commissioning to the user.

5.3 Activation of the communication port

- In the top menu select "Project → Options".
- From the window that appears, select the "Comm" tab and set the following values:
 - RS232 Port: **COM_ALL**
 - RS232 Speed: **57600**.
- Press "OK" to save changes.
- Press the "SAVE" button in the "Toolbar" to update the project.
- Press the red button "STOP" in the "Toolbar" to make the blue outline disappear.

- If communication between the PC and the module is correct, the words 'RS232' should not appear on the PC and in the lower right edge; COMx; Speed=57600".
- At this point we can continue with the other paragraphs.

5.4 How to Change Values

Generally the parameters that can be changed are highlighted with a certain color.

To change the value, do this:

- With the Windows Pointer, click once on the value you want to edit.
- To the right of the value will appear a gray square with a low arrow: Click on it once (see drawing 6).
- At this point there are two situations:
 1. The value to be modified is highlighted: in this case you can write a numerical value with the numerical keyboard.
 2. A window with written values appears: in this case it is mandatory to choose from the listed values.
- At the end of the choice, press ENTER key.
- If the value remains written and if there is no alarm message at the bottom left, then the parameter has been accepted and is already operational.

NAME	VALUE	UNIT
Parameters.EmulEncType	ppr 4096	
Parameters.StepDirPpr	1000	Ppr

Drawing 6: Example of change value

5.5 Rapid commissioning

First of all, check that the state of the front LEDs is as indicated in these points:

- The red led FLT is OFF.
- The green LED DO1 is fixed ON.
- The green LED DO2 is fixed ON.
- The green LED "ON" is FLASHING.

If you do not get this result you need to go to the paragraph 5.14 on page 21 to detect the cause of the problem.

At this point you can start putting into service that differs according to the type of user connected to the X7 connector. So from the simplest to the most difficult we can distinguish 4 different procedures:

1. Connection to an ALTER drive model PWM3D (go to page 14).
2. Connection to a CNC, PLC or other user that does NOT use Hall sectors (pins 10 to 15 of X7 are not used) (go to page 15).
3. Connection to a generic drive that does not include automatic phasing (e.g. ALTER BTM1 models) (go to page 15).

Follow the paragraph based on your configuration.

5.5.1 Connection to an ALTER drive model PWM3D

In this case the phasing procedure is fully automatic and is performed by the drive (see manual instruction of the PWM3D). The only operations to be performed in the module 13/013 are the following:

1. In the "Project Tree" select the group "Module Parameter Setting". At the bottom "Variable Watch" will appear some parameters that can be changed. Parameters to be inserted:
 - 1.1. Select the serial encoder model connected to the X6 connector, with "Parameters.EncoderType".
 - 1.2. Read the value of the parameter "Parameters.EmulEncType" (generally 4096 PPR): this value shall be used during the drive configuration and is the parameter of "resolution encoder"; see drive manual.
2. For **a64iA** or **aiA1000** type encoders it is necessary to check the motor plate and if necessary change the "Parameters.MotorPoleCoup" parameter located in the "Encoder phasing" block and enable the "Parameters.AutomPosIni" parameter to make the motor move until it reaches the zero position. On the other hand, the number of motor poles is fixed at 8 poles for the other types of encoders, therefore the "Parameters.MotorPoleCoup" parameter is fixed at 4 pole pairs.
3. In the "Project Tree" select the group "Save/Restore Parameters". In the first highlighted line of GREEN color click on the letter on the right to store the changed parameters. For further information, see paragraph 5.13 on page 19.
4. Make a complete rotation of the motor by hand so that in the group "Encoder status" the parameter "StsEncoder.PosIniOk" becomes "INIT OK".
5. Follow the installation explained in the instruction manual of the PWM3D drive, remembering that the parameters to be inserted in its display are:
 - 5.1. Motor pole (Motor Pole): The number of motor poles as selected in the "Parameters.MotorPoleCoup" (see point 2).
 - 5.2. Type of transducer (Feedback Type): TTL encoder.

5.3. Encoder Resolution (Encoder Lines): 4096 or the value read in the parameter "**Parameters.EmulEncType**" some points above.

The commissioning for this type of use ends here. If you want more information on the various menus available in the programming SW, you can see from the paragraph 5.6 from 16 page onwards.

5.5.2 Connection to equipment that does not use Hall sectors

The only operations to be performed in the module 13/013 are the following:

1. In the "Project Tree" select the group "Module Parameter Setting". At the bottom "Variable Watch" will appear some parameters that can be changed. Parameters to be inserted:
 - 1.1. Select the serial encoder model connected to the X6 connector, with "**Parameters.EncoderType**".
 - 1.2. Set the parameter "**Parameters.EmulEncType**" (generally 4096 PPR) to the value required by the device connected to X7.
2. In the group "Encoder phasing" disable the parameter "**Parameters.AutomPosIni**".
3. Put the equipment into operation and check that everything works properly. In the event that the direction of reading of the encoder is opposite to that desired, it is necessary to change:
 - 3.1. In the "Project Tree" select the group "encoder phase" and change the value of the parameter "**Parameters.EmulEncDir**" from NORMAL to REVERSE.
4. Try the operation again.
5. In the "Project Tree" select the group "Save/Restore Parameters". In the first highlighted line of GREEN color click on the letter on the right to store the changed parameters. For further information, see paragraph 5.13 on page 19.

The commissioning for this type of use ends here. If you want more information on the various menus available in the programming SW, you can see from the paragraph 5.6 from 16 page onwards.

5.5.3 Connection to a generic drive

In this case the phasing of the transducer is done completely with the module 13/013.

The operations to be carried out in the module 13/013 are as follows:

1. In the "Project Tree" select the group "Module Parameter Setting". At the bottom "Variable Watch" will appear some parameters that can be changed. Parameters to be inserted:
 - 1.1. Select the serial encoder model connected to the X6 connector, with "**Parameters.EncoderType**".
 - 1.2. Read the value of the parameter "**Parameters.EmulEncType**" (generally 4096 PPR): this value should be used during the drive configuration and is the "encoder resolution": see manual drive instructions.
2. For **a64iA** or **aiA1000** type encoders it is necessary to check the motor plate and if necessary change the "**Parameters.MotorPoleCoup**" parameter located in the "Encoder phasing" block and enable the "**Parameters.AutomPosIni**" parameter to make the motor move until it reaches the zero position. On the other hand, the number of motor poles is fixed at 8 poles for the other types of encoders, therefore the "**Parameters.MotorPoleCoup**" parameter is fixed at 4 pole pairs.
3. In the "Project Tree" select the group "Save/Restore Parameters". In the first highlighted line of GREEN color click on the letter on the right to store the changed parameters. For further information, see paragraph 5.13 on page 19.
4. Connect two buttons to the DI2 and DI3 inputs of the module 13/013 (for convenience).
5. It is absolutely essential to avoid damage to the motor, connect the DO1 output of the module 13/013 to the drive so that when it goes to logical level 0 the drive must disable and stop the motor.
6. Disconnect the motor from the mechanics, so that it can rotate freely without moving any part of the machine.
7. In the drive adjust the current limit to the minimum value.
8. In the drive set the "Number of motor poles" (if required) as selected in the "**Parameters.MotorPoleCoup**" (see paragraph 2), the transducer type (TTL encoder) and the resolution of the encoder as set in the module at the point 1 of this paragraph.
9. In the "Project Tree" select the group "encoder phase":
 - 9.1. Change the parameter "**CmdModule.PhaseReg**" to ACTIVE.
 - 9.2. Change the parameter "**SpeedIncAngleOffs**" to 10.0°/sec. This way the offset variation will be fast.
 - 9.3. Enable motor operation with a very low speed reference (1 volts).
 - 9.4. If the motor escapes and exceeds the speed set in the "**PhaseRegSpeed**" parameter (usually 500 RPM), the module is alarmed: flashes red led FLT and the DO1 output goes to 0. The drive should have blocked the motor.
 - 9.5. In this case it is necessary to reverse the direction of the encoder by changing the parameter "**Parameters.EncoderDir**" from *NORMAL* to REVERSE.
 - 9.6. Enable the drive again: the motor could lock or turn badly.
 - 9.7. Control the input DI2 or DI3 to vary the parameter "**Parameters.AngleEleOffs**" until you find the right one that makes the motor run correctly.
 - 9.8. If the above parameter has made a complete change of 360° and the right value is not found, you still need to change

"Parameters.EncoderDir", add 180° to the angle of "AngleEleOffs" and repeat from the previous point.

- 9.9. When you have found the right OFFSET value that allows a proper and controlled rotation of the motor, you can make a finer adjustment with the next points.
- 9.10. Change the parameter "SpeedIncAngleOffs" to 1.0°/sec. In this way the offset change will be slower.
- 9.11. Enable motor operation with a very low speed reference (approximately 10 RPM).
- 9.12. With the hand, the crank shaft of the motor must be braked lightly until the blows are heard on it due to the switching of the windings.
- 9.13. Try to control the input DI2 (or DI3) until you feel that the shots are reduced. Instead if the blows increase you have to act on the other digital input.
- 9.14. As an alternative to the use of DI2 and DI3 inputs, you can manually change the offset of the electrical angle by changing the parameter "Parameters.AngleEleOffs" in small steps.
- 9.15. The points from 9.12 to 9.14 are to be repeated until satisfactory operation is achieved.
- 9.16. At the end, return the parameter "CmdModule.PhaseReg" in "INACTIVE" mode.
- 9.17. If the motor runs in the opposite direction, the parameter "Parameters.EmulEncDir" from *NORMAL* to *REVERSE* must be changed.
10. At the end of this procedure, the modified parameters must be saved again: In the "Project Tree" select the group "Save/Restore Parameters". In the first highlighted line of GREEN color click on the letter on the right to store the changed parameters. For further information, see paragraph 5.13 on page 19.

The commissioning for this type of use ends here. If you want more information on the various menus available in the programming SW, you can see from the paragraph 5.6 from 16 page onwards.

5.6 Setting the module parameters

In the "Project Tree" select the group "Module Parameter Setting". In the lower part "Variable Watch" will appear the parameters to adapt the module to the equipment connected to the connector X7 and to the electric motor:

- **EncoderType**: select the serial encoder model connected to the module X6 connector.
- **EmulEncType**: select the type of encoder you want to emulate, among the following PPRs: 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192. The greater the number of PPRs, the higher the frequency of signals A, B on the X7 connector. From factory setting this parameter is 4096 PPR that offers an excellent ratio between precision and maximum frequency of signals. The maximum frequency of signals on A and B of the X7 connector is calculated with:

$F_{MAX} = \frac{PPR * RPM_{MAX}}{60}$	F_{MAX}: Maximum frequency (Hz) on conductors A, $\bar{A}$, B, $\bar{B}$. PPR: Number of pulse/turns set in the parameter "EmulEncType". RPM_{MAX}: maximum speed of rotation of the encoder (RPM).
--	---

- **StepDirPpr**: [3 ÷ 65000]. Set the number of pulses for each turn encoder you want to get on the frequency output (X8 connector). The greater the number of PPRs, the higher the signal frequency on the F+ and F- terminals.


NOTE: the parameter "StepDirPpr" must be set in conjunction with what is required by the connected tab downstream of the module. The F+ and F- outputs guarantee operation up to 4000KHz, but both the connection cable and the receiving card must be able to guarantee this frequency of signals. The frequency on F+ and F- terminals is as follows:

$F_{MAX} = \frac{PPR * RPM_{MAX}}{60}$	F_{MAX}: maximum frequency (Hz) on F+ and F- terminals. PPR: Number of pulse/turns set in the parameter "StepDirPpr". RPM_{MAX}: maximum speed of rotation of the encoder (RPM).
--	--

- **MotAlarmEnable**: enable alarm signal when the motor temperature probe intervenes.

5.7 Setting up digital inputs

In the "Project Tree" select the group "Digital Input Setting": here you can change the settings of the digital inputs and check the current logical state of each input.




Drawing 7: digital input stage

Please note that digital inputs have a fixed function and cannot be modified by the customer. See paragraph 4.3.8 on page 11 to associate the function with the digital input used.

NOTE: The yellow LEDs on the front signal the logical state of the digital input FIRST of the possible inversion of sign, then indicate the logical state of the input pin. With reference to drawing 7, the LED displays the logical state of the point marked with "Dix".

5.8 Setting digital outputs

In the "Project Tree" select the group "Digital Output Setting": here you can change the settings of the digital outputs and verify the current logical state of each output.



Drawing 8: digital output stage

Setup.Invert: with this parameter you can reverse the logical state of the associated digital input, considering that if the input terminal is floating corresponds to a state 0 (FALSE) instead if it is connected to +24Vcc the state is 1 (TRUE): this status is displayed with the related yellow LED on the front.

Value: this read-only parameter indicates the logical state available for blocks connected to that digital input.

Setup.Source: with this parameter you can view the source of the signal that will be used to control the digital output (you can NOT change the source).

Value: This read-only parameter indicates the logical state of the source selected with "Setup.Source".

Setup.Invert: with this parameter you can reverse the logical state of the associated digital output (only those highlighted), considering that the state 0 (FALSE) maintains the floating digital output instead the state 1 (TRUE) commands the output to +24Vcc.

Digital outputs already have established functions (see section 4.3.9 on page 11) and cannot be modified.

NOTE: The green LEDs on the front signal the logical state of the digital output AFTER the possible reversal of the sign, then indicate the logical state of the output pin. With reference to drawing 8, the LED displays the logical state of the point indicated with "Dox".

5.8.1 Signal sources for digital outputs


As indicated in the previous paragraph, in this module it is NOT possible to change the source of the signal that will be sent to the digital output by changing the parameter "Setup.Source". Below is a table showing the possible sources and the meaning of logical states to understand the function of a certain output:

EXIT	SOURCE	DESCRIPTION	State "FALSE"	State "TRUE"
DO1	Module OK	Whether there are alarms in the module.	Alarms present	Module OK
DO2	Com. Encoder INIT	The serial communication with the encoder has been initialised.	Not initialised	Initialised
DO3	Pos. Encoder INIT	The encoder position has been initialised with the passage in the ZERO position.	Not initialised	Initialised
DO4	Timeout	Signal that serial communication between module and encoder has exceeded the maximum time.	Communication OK	Timeout
DO5	DataRX Fault	Report error in the data received by the encoder	Communication OK	Data error rx
DO6	Enc. Intern. fault.	Signal the presence of alarms inside the encoder.	No alarms	Alarm present

Table 1: Signal sources for digital outputs

5.9 Setting analog outputs

In the "Project Tree" select the group "Setting Analog Outputs": here you can change the settings of the analog outputs and verify the current output value.



Drawing 9: Analog output stage

Setup.Source: with this parameter you can select the source of the signal that will be sent to the analog output.

Value: This read-only parameter indicates the percentage value of the source selected with "Setup.Source".

Setup.Abs: this parameter is used to use the source value with or without the sign.

Setup.Gain: this parameter is a multiplication factor of the source value. The range ranges from -9,999 % to +9,999 %.

Setup.Offset: this parameter is a fixed value that is added to the signal before being sent to the output pin. The range ranges from -100 % to +100 %.

Analog outputs already have established functions (see section 4.3.2 on page 7) that it is recommended to maintain. In any case, if necessary, it is possible to change or exchange the various signal sources between them.

5.10 Verification of encoder operation

In the "Project Tree" select the group "Encoder status": here you can check the operation of the serial encoder connected to the X6 connector:

- **ComIniOk:** indicate the serial communication with the encoder has been properly initialised.
- **PosIniOk:** indicate the incremental position received by the encoder has been initialised with the passage in the ZERO position.
- **AngleMec:** indicates current mechanical angle of the encoder in degrees.
- **AngleEle:** indicates current electrical angle of the encoder in degrees.
- **SpeedRpm:** indicates the current speed of the encoder in RPM.
- **RevMec:** indicates the number of mechanical revolutions carried out by the encoder.
- **Flags:** internal status of the encoder.
- **PosMec:** indicates the mechanical position considering both motor rpm and angular position.

In addition, selecting the oscilloscope "Rx data encoder & speed" or "Mechanical & electric angle (high speed)", you can read in graphic form the angle, speed of the encoder and other useful data to perform a diagnostic on the operation.

5.11 Frequency/direction output verification

In the "Project Tree" select the group "Step/Dir Output": Here you can check the operation of the output frequency/direction (see paragraph 4.3.7 on page 11) and change the PPR parameter. It is also possible to see on the oscilloscope the comparison between the pulse/turn counter of this function compared to the mechanical position of the encoder.

The data available are as follows:

- **Parameters.StepDirPpr:** This parameter is the same as you can find in the module parameters setting menu (see paragraph 5.6 on page 16) and is used to set the number of pulses/turns that will be generated on the F+ and F- terminals.
- **FioCounter:** displays a pulse counter generated by the output Frequency/direction. The value will always be between 0 and the number set in "Parameters.StepDirPpr" and is used to verify exactly how many pulses have been generated by the module.

NOTE: it is not guaranteed that when the encoder is in position 0° the FioCounter counter is at 0 counting value: it is a simple pulse counter.

5.12 Encoder phasing

In the "Project Tree" select the group "encoder phasing": this menu is used to adjust the phasing of the encoder compared to the motor in which it is mounted. For use see paragraph 5.5.3 (at page 15).

In this menu we find the following parameters:

- **CmdModule.PhaseReg:** this parameter activates or disables the "Encoder phase Adjustment" mode, which means:
 1. A maximum speed threshold is enabled which sends the module to "Fault" if it is exceeded. This is to protect the motor in case of "escape" due to the inverted transducer.
 2. With the inputs DI2 and DI3 you can increase or decrease the offset of the electrical angle and then the phasing. It is not necessary to use digital inputs because you can also change the offset parameter with the SW of the PC; this possibility

has been inserted to facilitate the operation.

- **SpeedIncAngleOffs:** $[0,1 \div 25,5^\circ/\text{sec}]$. This parameter adjusts the increment speed (or decrease) in degrees/sec of the parameter "Parameters.AngleEleOffs" that will occur when you control the DI2 or DI3 inputs.
- **Parameters.MotorPoleCoup:** $[1 \div 10]$. This parameter sets the number of pole pairs of the motor.
- **Parameters.AutomPosIni:** by activating this parameter the angular and electrical position will perform "virtual" rotations until the encoder can reach its zero position. The purpose of this function is to make the motor move even if the electrical angle is not right: This happens because some types of serial encoders do not have the correct electrical position at power on.
- **PhaseRegSpeed:** $[0 \div 30000 \text{ RPM}]$. Set the maximum speed threshold during phasing mode. If for any reason the motor speed exceeds this threshold, the module goes to "Fault" signalling the "Over-speed" alarm.
- **Parameters.AngleEleOffs:** $[-180^\circ \div 180^\circ]$. Set a value of Offset that will be added to the true electric angle of the motor to create an offset and compensate the position of the encoder with respect to the motor rotor. This parameter is automatically changed with DI2 and DI3 inputs.
- **Parameters.EncoderDir:** this parameter is used to reverse the direction of the encoder and thus the sequence of the Hall sectors with respect to motor rotation.
- **Parameters.EmulEncDir:** this parameter is used to reverse the direction of the output "Emulated encoder" in case the motor does not rotate in the required direction.
- **StsEndat.SpeedRpm:** this read-only parameter indicates the current speed of the encoder in RPM.
- **StsModule.AngleEle:** this read-only parameter indicates the current electrical angle of the motor in degrees.

By selecting one of the oscilloscopes indicated with "Hall sectors" you can see the logical states of the outputs combined with the Hall sectors (SE1, SE2, SE3) in comparison with the mechanical and electrical angles of the motor.

Please note that: $AngleElectric = AngleMeccanic \times PolePair$ and that $PolePair = \text{Parameters.MotorPoleCoup}$.

5.13 Save/Restore Parameters

All changes made to the parameters shall remain valid until the supply to the auxiliary services is lacking; if these changes have not been saved (stored) they will be lost and on the next restart the old data will be found. This feature has the merit that, in case of accidental modification of one or more parameters, it is sufficient to remove the power for a few seconds and then restore it to return to the situation of the last save.

In this paragraph we will see how to memorise the parameters in order to find them at the next start.

Name	Value
Backup start	press to start -->
Backup status:	
Full memory?	NO
Erase error code:	0
Read error code:	0
Error code write:	0
Factory data reset:	INACTIVE
Firmware download:	INACTIVE
BootLoader version:	2.00

Drawing 10: Save/Restore Parameters

In the "Project Tree" select the group "Save/Restore parameters": In the "Variable Watch" zone the parameters will appear as in drawing 10.

Save parameters: in the 1st row we find the button to start the "backup" procedure, follow these points:

- With the mouse pointer press once on the words "press to start".
- A gray square will appear (see picture on the side). Press with the mouse pointer on the square.
- The word "START" will appear. Press the mouse pointer on the lettering.
- After a few moments in the 2nd line the words "BACKUP OK" (see drawing 11) will appear if the copy is finished correctly; otherwise "BACKUP ERROR" will appear and there will be error codes in the next rows. If necessary, these codes can be communicated to ALTER to verify the malfunction.
- If the copy is finished correctly, you can also turn off the module without risk of losing the input values.

Name	Value
Backup start	press to start -->
Backup status:	BACKUP OK
Full memory?	NO

Drawing 11: Backup terminated

Restore parameters: In case of need it is possible to restore the factory parameters. Of course, all changes made during commissioning will be lost. In order to avoid accidental restoration, the procedure to be carried out is more complex:

Error code write:	0
Factory data reset:	ACTIVE
Firmware download:	INACTIVE
BootLoader version:	2.00

Drawing 12: Restoring Parameters


- With the mouse pointer press once on the inscription “INACTIVE” on the orange color row with the words “Factory data reset”.
- A gray square will appear. Press with the mouse pointer on the square.
- A menu with two entries will appear: INACTIVE and ACTIVE. Select the item “ACTIVE”.
- At this point you have to get a situation as in drawing 12.
- Remove the power supply of the services for a few seconds and then restore it.
- At the end of the restart will be loaded the original parameters, but to make them definitive you need to overwrite the previous ones, following the procedure “Save parameters” in this paragraph.

NOTE: By forcing the user to follow this parameter restoration procedure, it is ensured that even in case of unwanted command the previous data is not lost. In fact, even if the user accidentally performed a restoration, there is still the possibility of recovering the error made: simply do NOT save the restored parameters, turn off and switch on again the module to find the previous parameters again.

5.13.1 Transfer parameters from module to PC


You can transfer the parameters from the module to the PC and save them to the HD for storage or to restore them to the module in case of replacement. With the following procedure will be transferred all the parameters currently used in the module (i.e. those displayed in the various menus) that could also be different from those saved in the internal memory:

1. In the programming software click on the top menu "Tools → S-Record Transfer...". A window will appear divided into four zones with set values or buttons to press.
2. Check that everything is set at the top as in the following figure (except “address used”):



Drawing 13: Target Interface

3. Check that everything is set at the bottom as shown in the following figure:



Drawing 14: Flash Programmer


4. Press the “Read Flash...” button at the bottom left. A window will open that displays the data download phase.
5. After a few moments another window will appear with the request to indicate where to save the file.
6. It is recommended to create a folder “ALTER” in “C:” and assign a name to the data set that can then be easily located. In this example we will call it “Prova_001.srec”.
7. Press "Close & Save Settings" at the bottom right to close the window.

NOTE: the parameters downloaded and stored on the PC HD can only be used to be transferred into the same module type with the procedure explained in the next paragraph. It is forbidden to edit the file or transfer the parameters of another product: the module notices this error and blocks the transfer.

5.13.2 Transfer parameters from PC to module

The parameters that have been stored on the PC with the procedure of the previous paragraph, can be transferred to the module with the following points:

1. In the programming software click on the top menu "Tools → S-Record Transfer...". A window will appear divided into four zones with set values or buttons to press.
2. Check that everything at the top is set as in drawing 13 and bottom as in drawing 14.
3. In the middle “Input file” press the right button “...” and select the file to be transferred to the module: for example, we transfer the data set stored in the previous paragraph. A situation similar to that of the following figure should be achieved:



Drawing 15: File input

4. Press the “Write Flash” button at the bottom center: a window will appear showing the progress of the data transfer phase.
5. If the transfer takes place without errors, you will see the words “Flash Write operation finished successfully” appear in the line “Status”.
6. Press “Close & Save Settings” at the bottom right to close the window.
7. The new parameters are available in the module and can be checked by selecting the various “Project Tree” menus. To make them definitive you need to save them in the internal memory of the module following the procedure indicated in the paragraph 5.13 on page 19, otherwise the last parameters that were stored internally will return to the next reboot of the module.

NOTE: the parameters downloaded and stored on the PC's HD can only be used to be transferred into the same module type. It is forbidden to edit the file or transfer the parameters of another product: the module notices this error and blocks the transfer.

5.14 Module alarms

In the “Project Tree” select the group “Module alarms”: here you can see the states of all possible alarms in the module.

When the red “FLT” LED flashes or the “OK module” output goes to level 0, it means that there is an alarm present. To understand the cause you have to go to this menu is to check which of these alarms has the inscription “ALARM”.

List of alarms and possible resolution:

ALARM	CAUSE	RESOLUTION
StsEncoder.TimeOutFlt	Exceeding the maximum response time by the serial encoder	Check connection cable, serial line connection, encoder conditions.
StsEncoder.DataRxFlt	Errors in the data received by the serial encoder.	Use proper connection cable, arrange cable away from sources of disturbance, check encoder conditions, check the connection between module and encoder. If necessary, the parameter “ ErrCntLimit ” can be increased to tolerate more communication errors before reporting.
StsEncoder.MotorOverTemp	The motor is overheated	Reduce the load on the motor.
StsEncoder.EncInternalFlt	There are errors inside the encoder.	Replace encoder.
Stsmodule.OverSpeed	Exceeded the speed threshold, during the “phase” mode.	If the phasing is over, disable the command. If the motor has escaped during phasing, the direction of the encoder shall be reversed.
StsDriver.AdcLim	Saturation of the A/D converter inside the module.	Verify that the above signals are within the prescribed range: AI1, AI2, AI3.
StsDriver.I2cFlt	Internal communication problem.	Restart the module and see if it appears again. Notify ALTER Technical Service.
StsDriver.OutFlt	Overload on one or more digital outputs.	Disconnect the wires connected to the digital outputs and after resetting the alarm reconnect them one to one to verify what is causing the fault. In the case of capacitive loads driven by digital outputs, it may be necessary to connect a resistance of 100 Ω ½Watt in series to the wire.
StsDriver.SupFlt	Auxiliary power out of tolerance.	Check the supply voltage of the services that is within the permissible range. Select the menu “Auxiliary Power supply voltages”, check which one is wrong and notify the ALTER technical service.
StsDriver.WdogFlt	Cycle time out of tolerance.	Notify ALTER Technical Service.

Table 2: Module alarm

Modifiable parameters:

- **Parameters.ErrCntLimit:** [1 ÷ 255]. This parameter indicates the number of communication error cycles (DataRxFlt) that are tolerated before generating an error and blocking the module (Fault). In case of disturbances, poor quality cable or other problems that cause the “StsModule.ComFlt” alarm to appear, you can try to increase this value.
- **Parameters.AutoClrFlt:** [0 ÷ 255]. With this parameter you can activate the automatic reset in case of alarm caused by the

encoder, setting it to a value other than 0. This value entered will be the delay in cents of a second that will occur from the disappearance of the alarm cause to the reset of the module.

5.14.1 Reset alarms

After deleting the cause that produced the alarm it is possible to cancel the signal and restore the normal functioning of the module. To do this you can do this in 3 different ways:

1. Remove service power for a few seconds and then restore it.
2. Control the digital input 1 (DI1) with a pulse from 0V to +24V for at least one second: this is used to reset from a PLC or CNC.
3. In the “Project Tree” select the group “Allow module” and press in the line where it says “CmdModule.ClrFlt”; select the words RESET.

If the FLT LED continues to flash even after completing one of the points listed above, then it means that the cause of the alarm has not been resolved: See the “Alarms Form” menu (see paragraph 5.14 on page 21).

NOTE: you can activate the automatic reset of the alarms generated by the encoder, using the parameter “AutoClrFlt”, see previous paragraph.

5.15 Diagnostics

In the “Project Tree” select the group “Diagnostics”: here you can find some data that can be useful for talking to the ALTER technical service.


Chapter 6 - Annexes

6.1 Led Summary Table

The following table lists the components as they appear on the front of the module, starting from the upper left edge.

NAME		DESCRIPTION	Reference
USB	USB	USB communication between module and PC	Paragr. 5.3 on page 13
FLT	Fault	Alarm module	Paragr. 5.14 on page 21
DI1	Digital Input 1	Command Digital input 1 (Reset Alarms)	Paragr. 4.3.8 on page 11
DI2	Digital Input 2	Command Digital input 2 (command increases offset)	Paragr. 4.3.8 on page 11
DI3	Digital Input 3	Command Digital input 3 (command decreases offset)	Paragr. 4.3.8 on page 11
DI4	Digital Input 4	Command Digital input 4 (not used)	Paragr. 4.3.8 on page 11
DI5	Digital Input 5	Command Digital input 5 (not used)	Paragr. 4.3.8 on page 11
DI6	Digital Input 6	Command Digital input 6 (not used)	Paragr. 4.3.8 on page 11
DI7	Digital Input 7	Command Digital input 7 (not used)	Paragr. 4.3.8 on page 11
DI8	Digital Input 8	Command Digital input 8 (not used)	Paragr. 4.3.8 on page 11
DI9	Digital Input 9	Command Digital input 9 (not used)	Paragr. 4.3.8 on page 11
DO1	Digital Output 1	Status Digital output 1 (signal OK MODULE)	Paragr. 4.3.9 on page 11
DO2	Digital Output 2	Status Digital output 2 (signal Communication with ENCODER)	Paragr. 4.3.9 on page 11
DO3	Digital Output 3	Status Digital output 3 (signal position ENCODER initialised)	Paragr. 4.3.9 on page 11
DO4	Digital Output 4	Status Digital output 4 (signal TIMEOUT ERROR)	Paragr. 4.3.9 on page 11
DO5	Digital Output 5	Status Digital output 5 (signal received DATA ERROR)	Paragr. 4.3.9 on page 11
DO6	Digital Output 6	Status Digital output 6 (signal INTERNAL ENCODER ALARM)	Paragr. 4.3.9 on page 11
ON	Module ON	Module powered and running (flashing).	Paragr. 5.1 on page 13

Chapter 7 - Mechanical characteristics



Drawing 16: Dimensions

Mass: 0,8 Kg

Alter Elettronica s.r.l.

Via Ezio Tarantelli 7
15033 Casale Monferrato (AL)
ITALY

Tel. +39 0142 77337

Internet: <http://www.alterelettronica.it>

email: info@alterelettronica.it